



- KEY**
- 01 MULTIPLE CONNECTORS
 - 02 FRONT RIGHT TURN INDICATOR
 - 03 HEAD LIGHT ASSEMBLY
 - 04 FRONT LEFT TURN INDICATOR
 - 05 LOW-BEAM/HIGH-BEAM BULB
 - 06 TAIL LIGHT BULB
 - 07 HIGH-BEAM LIGHT RELAY
 - 08 LIGHT LOGIC RELAY
 - 09 HORN
 - 10 LEFT LIGHT SWITCH
 - 11 INSTRUMENT PANEL DIAGNOSIS
 - 12 INSTRUMENT PANEL
 - 13 FRONT STOP SWITCH
 - 14 REAR STOP SWITCH
 - 15 CLUTCH SWITCH
 - 16 KEY SWITCH
 - 17 MAIN INJECTION RELAY
 - 18 IMMOBILIZER AERIAL
 - 19 REAR LEFT TURN INDICATOR
 - 20 REAR RIGHT TURN INDICATOR
 - 21 LICENSE PLATE LIGHT BULB
 - 22 REAR LIGHT ASSEMBLY
 - 23 RECOVERY LOGIC RELAY
 - 24 AUXILIARY FUSES
 - 25 VOLTAGE REGULATOR
 - 26 GENERATOR
 - 27 STARTER MOTOR
 - 28 START-UP RELAY
 - 29 MAIN FUSE
 - 30 BATTERY
 - 31 SECONDARY INJECTION RELAY
 - 32 OIL PRESSURE SENSOR
 - 33 FAN
 - 34 FAN CONTROL SWITCH
 - 35 RIGHT LIGHT SWITCH
 - 36 -
 - 37 FUEL RESERVE SENSOR
 - 38 FUEL PUMP
 - 39 ECU DIAGNOSIS
 - 40 FALL SENSOR
 - 41 SIDE STAND SWITCH
 - 42 GEAR SENSOR
 - 43 SPEED SENSOR
 - 44 REAR CYLINDER PRESSURE SENSOR
 - 45 FRONT CYLINDER PRESSURE SENSOR
 - 46 REAR CYLINDER THROTTLE
 - 47 FRONT CYLINDER THROTTLE
 - 48 INTAKE AIR TEMPERATURE SENSOR
 - 49 WATER TEMPERATURE SENSOR
 - 50 ECU
 - 51 HAND GRIP POSITION SENSOR
 - 52 REVOLUTION SENSOR
 - 53 FRONT CYLINDER COIL
 - 54 REAR CYLINDER COIL
 - 55 FRONT CYLINDER COIL
 - 56 REAR CYLINDER COIL
 - 57 SPARK PLUG
 - 58 FRONT CYLINDER INJECTOR
 - 59 REAR CYLINDER INJECTOR
 - 60 LAMBDA PROBE

- COLOUR KEY**
- Ar Orange
 - Az Sky blue
 - B Blue
 - Bi White
 - G Yellow
 - Gr Grey
 - M Brown
 - N Black
 - R Red
 - Ro Pink
 - V Green
 - Vi Purple

- DIAGRAM COLOURS - KEY**
- RED POWER SUPPLY
 - BLACK GROUND
 - GREEN ENABLING / SIGNAL
 - SKY BLUE ENABLING / SIGNAL